

# Marklin 7686 Turntable Quick Reference for Switchboard 15 (Default)

Date: 06-05-2010 Revised layout

Marklin Switchboard 15		
KEY SET	FUNCTION BUTTONS	SUCCESSIVE ADDRESS
1	END INPUT	m225r m225g
2	CLEAR TURN 180	m226r m226g
3	STEP CW > STEP CCW <	m227r m227g
4	SELECT CW ► SELECT CCW ◀	m228r m228g
5	SPOKE 1 SPOKE 2	m229r m229g
6	SPOKE 3 SPOKE 4	m230r m230g
7	SPOKE 5 SPOKE 6	m231r m231g
8	SPOKE 7 SPOKE 8	m232r m232g
9	SPOKE 9 SPOKE 10	m233r m233g
10	SPOKE 11 SPOKE 12	m234r m234g
11	SPOKE 13 SPOKE 14	m235r m235g
12	SPOKE 15 SPOKE 16	m236r m236g
13	SPOKE 17 SPOKE 18	m237r m237g
14	SPOKE 19 SPOKE 20	m238r m238g
15	SPOKE 21 SPOKE 22	m239r m239g
16	SPOKE 23 SPOKE 24	m240r m240g

## Programming for the first time or when changes are required.

Press the **INPUT** button within the **first 5 seconds** after turning on the digital layout. The turntable will rotate automatically to the last stored position for spoke track 1 and sounds a beep.

Use the **STEP < >** buttons to locate the new spoke track 1, by pressing the **CLEAR** button all spoke track positions previously stored in memory will be deleted and the **new Spoke 1 track will be entered.**

Using the **STEP >** button, position the new spoke track location and press **INPUT** button before turning the turntable to the next position. When all spokes tracks have been entered end the programming procedure by pressing the **END** button. The turntable is now programmed and the memory remains in effect even when the digital layout is switched off.

## Recovery procedure when correct indexing is lost

If the spoke track position no longer corresponds to the button assigned to it. The digital layout must be turned off, wait a few seconds then turn it on again.

Press the **INPUT** button within the **first 5 seconds** after turning on. Position the turntable to spoke track 1 using the **STEP < >** buttons and press the **END** button when the turntable is in the correct position for spoke track 1.

**TIP:** Wire the yellow (L) connection of the 7687 digital controller to a k84 contact then you can power off and on the turntable without turning off the entire layout.

**Warning,** don't press the **CLEAR** button during this procedure, as all stored spoke track locations will be deleted from memory.

Function Monitoring for Marklin 7686 Turntable			
Red (rt)	Green (gn)	Yellow (ge)	Functions
		✘	Ready for programming
●		✘	Positioning
	●	✘	Position 1 reached
		●	Spoke track not stored in memory
	●	●	Spoke track stored in memory
●		●	Looking for spoke track
●			Turntable in operation
	●		Spoke track reached
✘		✘	Disturbance
● = ON			
✘ = BLINKING			